



A9920515 1.5 mtr conection cable male / female



Always disconnect the mains of the LED driver before plugging or unplugging the LED`s !!
The LED`s will be damaged or destroyed because of the high voltage present on the driver output
when there is no load connected

